



# Understanding Units of Measurement

Terrie K. Boguski, P.E.

Technical environmental reports involving soil, water, or air contamination often report numerical values in units unfamiliar to people who don't routinely read these types of reports. The different units of measurement

can be confusing. This brief is intended to help people understand measurement units they may see in technical environmental reports. Examples of typical units of measurement are given below.

## Numbers

Million = 1,000,000

Billion = 1,000,000,000

Trillion = 1,000,000,000,000

One millionth = 0.000001

One billionth = 0.000000001

One trillionth = 0.000000000001

## Mass

28 grams = about 1 ounce

1 kilogram (kg) = 1,000 grams

1 milligram (mg) = 1/1,000 gram = 0.001 gram

1 microgram (ug) = 1/1,000,000 gram = 0.000001 gram

1 nanogram (ng) = 1/1,000,000,000 gram = 0.000000001 gram

1 picogram (pg) = 1/1,000,000,000,000 gram = 0.000000000001 gram

## Volume

One liter (L) = 1.06 quarts

One cubic meter (m<sup>3</sup>) = 35.31 cubic feet (ft<sup>3</sup>)

One cubic meter (m<sup>3</sup>) = 1,000 liters (L)

One liter (L) = 1,000 milliliter (ml) = 1,000 cubic centimeters

## **Concentrations in Soil**

Concentrations of chemicals in soil are typically measured in units of the mass of chemical (milligrams, mg or micrograms, ug) per mass of soil (kilogram, kg). This is written as mg/kg or ug/kg. Sometimes concentrations in soil are reported as parts per million (ppm) or parts per billion (ppb). Parts per million and parts per billion may be converted from one to the other using this relationship: 1 part per million = 1,000 parts per billion.

For soil, 1 ppm = 1 mg/kg of contaminant in soil, and 1 ppb = 1 ug/kg. A measurement of 6 mg/kg is the same as 6 ppm or 6,000 ppb, which is equal to 6,000 ug/kg.

## **Concentrations in Water**

Concentrations of chemicals in water are typically measured in units of the mass of chemical (milligrams, mg or micrograms, ug) per volume of water (liter, L, l).

Concentrations in water can also be expressed as parts per million (ppm) or parts per billion (ppb). Parts per million and parts per billion may be converted from one to the other using this relationship: 1 part per million = 1,000 parts per billion.

For water, 1 ppm = approximately 1 mg/L (also written as mg/l) of contaminant in water, and 1 ppb = 1 ug/L (also written as ug/l). A measurement of 6 mg/L is the same as 6 ppm or 6,000 ppb, which is equal to 6,000 ug/L.

A way to visualize one part per billion (ppb) in water is to think of it as one drop in one billion drops of water or about one drop of water in a swimming pool. One part per million is about 1 cup of water in a swimming pool.

Occasionally, concentrations of chemicals in water may be written as grams per cubic meter (g/m<sup>3</sup>). This is the same

as grams per 1,000 liters, which may be converted to milligrams per liter (mg/L). Therefore,  $1 \text{ g/m}^3 = 1 \text{ mg/L} = 1 \text{ ppm}$ . Likewise, one milligram per cubic meter ( $\text{mg/m}^3$ ) is the same concentration in water as one microgram per liter ( $\text{ug/L}$ ), which is about 1 ppb.

### Concentrations in Air

Concentrations of chemicals in air are typically measured in units of the mass of chemical (milligrams, micrograms, nanograms, or picograms) per volume of air (cubic meter or cubic feet). However, concentrations may also be expressed as parts per million (ppm) or parts per billion (ppb) by using a conversion factor. The conversion factor is based on the molecular weight of the chemical and is different for each chemical. Also, atmospheric temperature and pressure affect the calculation.

Typically, conversions for chemicals in air are made assuming a pressure of 1 atmosphere and a temperature of 25 degrees Celsius. For these conditions, the equation to convert from concentration in parts per million to concentration in milligrams per cubic meter ( $\text{mg/m}^3$ ) is as follows:

$$\text{Concentration (mg/m}^3\text{)} = 0.0409 \times \text{concentration (ppm)} \times \text{molecular weight}$$

To convert from  $\text{mg/m}^3$  to ppm, the equation is as follows:

$$\text{Concentration (ppm)} = 24.45 \times \text{concentration (mg/m}^3\text{)} \div \text{molecular weight}$$

The same equations may be used to convert micrograms per cubic meter ( $\text{ug/m}^3$ ) to parts per billion (ppb) and vice versa:

$$\text{Concentration (ug/m}^3\text{)} = 0.0409 \times \text{concentration (ppb)} \times \text{molecular weight}$$

$$\text{Or, concentration (ppb)} = 24.45 \times \text{concentration (ug/m}^3\text{)} \div \text{molecular weight}$$

Here is an example. The molecular weight of benzene is 78. If the concentration of benzene in air is  $10 \text{ mg/m}^3$ , convert to the units of ppm by multiplying  $24.45 \times 10 \text{ mg/m}^3 \div 78 = 3.13 \text{ ppm}$ .

Note: Sometimes you will see chemical concentrations in air given in concentration per cubic feet ( $\text{ft}^3$ ) instead of concentration per cubic meter ( $\text{m}^3$ ). The conversion from cubic feet to cubic meter and vice versa is as follows:  $1 \text{ ft}^3 = 0.02832 \text{ m}^3$  and  $1 \text{ m}^3 = 35.31 \text{ ft}^3$ .

### ABOUT THE AUTHOR

Terrie K. Boguski, P.E., is the Assistant Technical Director of the CHSR at Kansas State University (tboguski@ksu.edu).

This publication was edited, designed, and printed by the Center for Hazardous Substance Research (CHSR), Kansas State University, as part of the outreach programs for communities. Programs include Technical Assistance to Brownfields communities (TAB), Technical Outreach Services to Communities (TOSC), and Technical Outreach Services to Native American Communities (TOSNAC). Contact the CHSR at 104 Ward Hall, Manhattan, KS 66506; phone: 1-800-798-7796; fax: 785-532-5985; website: <http://www.engg.ksu.edu/CHSR/>